




DIGITAL COLOR PRINTER

MODEL

**CP8000DW**

**OPERATION MANUAL**



THIS OPERATION MANUAL IS IMPORTANT  
TO YOU.  
PLEASE READ IT BEFORE USING YOUR  
DIGITAL COLOR PRINTER.



# DIGITAL COLOR PRINTER

This digital color printer complies with the requirements of the EC Directive 89/336/EEC, 73/23/EEC and 93/68/EEC.

The electro-magnetic susceptibility has been chosen at a level that gains proper operation in residential areas, on business and light industrial premises and on small-scale enterprises, inside as well as outside of the buildings. All places of operation are characterised by their connection to the public low voltage power supply system.



## **INFORMATION**


This Class A digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

### **WARNING :**

TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS  
APPLIANCE TO RAIN OR MOISTURE.

	<b>CAUTION</b> RISK OF ELECTRIC SHOCK DO NOT OPEN	
<p><b>CAUTION :</b> TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK) NO USER-SERVICEABLE PARTS INSIDE REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.</p>		



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated “dangerous voltage” within the product’s enclosure that may be of sufficient magnitude to constitute the risk of electric shock.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

**NOTE:**

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his or her own expense.

**WARNING:**

Use the included AC power cord so as not to interfere with radio and television reception. If you use other cables, it may cause interference with radio and television reception.

PRECAUTIONS
FEATURES
CONNECTIONS
PREPARATION
TROUBLE-SHOOTING
OTHERS

## CONTENTS

Contents .....	1
Safety precautions .....	2-4
Special features .....	5
Unpacking .....	6
Features and functions .....	7-8
Front panel .....	7
Rear panel .....	8
Connections .....	9-14
Connection with SCSI data signal equipment .....	9
Connection with Parallel data signal equipment .....	10
Parallel data signal allocation .....	11-13
Connection with USB data signal equipment .....	14
Before operation .....	15-20
Print paper and ink sheet .....	15
Installation of ink sheet .....	15-16
Installation of print paper .....	17-18
Usage and keeping of paper sheet set .....	19
Installation of printer driver .....	20
Error messages and countermeasures .....	21-23
Indication on the front panel and countermeasures .....	21
Overcoming paper jams .....	22
Before calling for service .....	23
Assignment of transportation package .....	23
Cleaning .....	24
Specifications and options .....	25

PRECAUTIONS
FEATURES
CONNECTIONS
PREPARATION
TROUBLE-SHOOTING
OTHERS

# SAFETY PRECAUTIONS

---

In the interest of safety, please observe the following precautions:

## POWER REQUIREMENT

This Digital Color Printer is designed to operate on 120V AC 50/60Hz in U.S.A. and Canada, 220V-240V AC 50/60Hz in Europe. Never connect to any outlet or power supply having a different voltage or frequency.

**WARNING : THIS APPARATUS MUST BE EARTHED.**

**AVERTISSEMENT: CET APPAREIL DOIT ETRE MIS A LA TERRE.**

## PROTECTIVE MEASURES

### IF ABNORMALITIES ARISE, .....

Use of the unit during emission of smoke or abnormal sounds (without adopting countermeasures) is dangerous. In such a case, unplug the power cord from the source outlet immediately, and request maintenance service from the sales dealer.

### NEVER INSERT ANY OBJECT INTO THE UNIT

Foreign objects of any kind inserted into this unit constitute a safety hazard and can cause extensive damage.

### DO NOT PLACE ANYTHING ON THE DIGITAL COLOR PRINTER

Heavy objects placed on the Digital Color Printer can cause damage or obstruct proper ventilation.

### PROTECT THE POWER CORD

Damage to the power cord may cause fire or shock hazard. When unplugging, hold by the plug only and remove carefully.

### DO NOT PLACE WATER CONTAINERS ON THE UNIT

Do not place flower vases, and other water-holding containers on the device. If, for some reason, water seeps to the inside of the unit, unplug the power cord from the source outlet, and contact the sales dealer. If used without corrective measures, the unit may be damaged.

"In the interest of safety, avoid handling of liquids near the unit."

### DO NOT REMOVE THE CABINET

Touching internal parts is dangerous, besides, it may lead to malfunction. Contact the sales dealer to carry out internal checks and adjustments. Before opening the cover for eliminating a jammed paper, etc., be sure to disconnect the power cord plug.

### UNPLUG THE POWER CORD DURING A LONG ABSENCE

Turn off the main power switch and unplug the power cord during a long absence.

### WHEN TRANSPORTING THE UNIT

When transporting the unit, remove the ink sheet and print paper from the unit.

### BE CAREFUL AROUND PRINT PAPER EXIT SLOT

Don't insert your hand or any material into the paper exit slot during printing.

Do not touch the cutter blade inside the paper exit slot.

Otherwise, your finger will be injured.

### DO NOT TOUCH THE THERMAL HEAD

Do not touch your hand to the thermal head (located inside the unit).

The thermal head is heated to high temperature.

This may cause injury.

### BE CAREFUL WITH THE PRINTING UNIT

Do not move the unit while the printing unit is sliding out. This may cause injury.

Be careful not to catch your finger in the printing unit when the printing unit is being retracted into the unit.

### CONNECTION CABLES

Use the provided power cord.

## INSTALLATION LOCATIONS

### MAINTAIN GOOD VENTILATION

Ventilation slots and holes are provided on the rear and both sides of this unit. Place the unit on a hard and level surface and locate at least 10cm (4 inches) from walls to insure proper ventilation. When putting the unit on the system rack, take a space between the unit and the back and sides of the rack.

### UNSUITABLE LOCATIONS

Avoid shaky places or hot-springs areas where hydrogen sulfide and acidic ions are likely to be generated.

### PLACES WITH HIGH HUMIDITY AND DUST

Do not place the unit at a high humidity and dusty locations. They can cause extensive damage to this unit. Avoid places where the unit is likely to be exposed to oily fumes and vapors.

### PLACES NOT LIKELY TO BE EXTREMELY HOT

Places exposed to direct sunlight, or near heating appliances can attain extremely high temperatures, which may deform the cabinet, or can become a prime cause of damage.

### PLACES THE UNIT ON A HORIZONTAL LEVEL

The unit is likely to be affected if it is placed in slanted conditions or in an unstable places.

### PROTECT AGAINST DEW FORMATION

In extremely cold regions, if the unit is moved quickly from an extremely cold place to warmer one, dew is likely to be formed. If dew is formed, printing is not possible.

### OPERATING AMBIENT TEMPERATURE RANGE

The operating ambient temperature range is 5°C-40°C (41°F-104°F) and the humidity of 20-80%. When using the unit on the system rack, be sure to keep this ambient temperature inside the rack.

## FOR LONG OPERATING LIFE

### UNSUITABLE MATERIALS FOR THE DIGITAL COLOR PRINTER

Coat flaking and deformation are likely to occur if the unit is wiped with chemical dusters, benzene, thinner or any other solvent, if rubber or PVC items are left in contact with the unit for extended duration, or if the unit is sprayed with insecticide.

### CARE OF THE CABINET

Unplug and clean with a soft cloth slightly moistened with a mild soap and water solution. Allow to dry completely before operating. Never use petroleum base solutions or abrasive cleaners.

### HEAD ABRASION

The thermal head, like the video head, wears out. When it is abraded, it becomes hard to print out fine details of the picture. In such a case, it is necessary to replace the thermal head. Consult with the sales dealer for replacing the head.

### CONNECTING DEVICES

Read thoroughly "Operating Precautions" of the instruction booklets for the devices connected with the Digital Color Printer. The power cord must be disconnected after printing is over.

### CAUTION ON RELOCATING

When transporting this unit, make sure it is not likely to be subjected to impacts. They can be a prime cause for damage. Further, make sure to disconnect the power cord from the power outlet, and the cables from the connected devices.

## ***SAFETY PRECAUTIONS***

---

### **OTHER CAUTIONS**

Dust or other foreign matter adhering to the print paper or the ink cassette, or deformation resulting from exposure to extremely low or high temperatures could cause loss of color, uneven color or lines, or wrinkles in the print images.

**NOTE:**

**YOUR UNDERSTANDING IS REQUESTED FOR THE LOSS OF IMAGES IN MEMORY DUE TO THE SUDDEN OCCURRENCE OF A MALFUNCTION.**

As for paper sheet set, refer to "Print paper and ink sheet".

# SPECIAL FEATURES

## SPECIAL FEATURES

### 4 PRINT SIZES ARE AVAILABLE ACCORDING TO THE PURPOSE

4 printing sizes, W size (max.152 x 229 mm), X size (max.127 x 178 mm), L size (max.152 x 102 mm) and M size (max.127 x 89 mm), are selectable.

### HIGH SPEED PRINTING

Normal printing speed is approx.15 seconds ( in M size print). Use of roll paper shortens the time for installing and removing.

### LARGE CAPACITY PRINTING

Maximum of 240 prints per roll with M size media. Large capacity per roll reduces time for frequent media loading.

### HIGH QUALITY PRINTING

CP8000DW is a dye sublimation thermal transfer color printer which produces superior high quality images. It also produces a continuous tone at 256 gradient and 16.7 million colors for each YMC.

### 304 PPI HIGH RESOLUTION

CP8000DW has a 304 PPI high resolution for precise illustrations and sharp photographic images.

### WIDE COMPATIBILITY WITH A VARIETY OF INTERFACE AND SYSTEMS

- (1) Input and output control signals from SCSI II, IEEE1284, and USB interfaces.
- (2) Reduced time of PC processing by a newly developed printer driver.

PRECAUTIONS

FEATURES

CONNECTIONS

PREPARATION

TROUBLE-  
SHOOTING


OTHERS

# UNPACKING


## UNPACKING

Take the printer out of the box by the following procedures. Make sure to check the contents.

**1** Open the top of the box.




**2** Remove the cushion with contents.




**3** Take the printer out of the box carefully.


You can pull out the printer by holding the print outlet on the front panel and the bottom of the rear panel.  
Make sure to keep the printer horizontally.



**4** Unwrap the packing.




## ■ CONTENTS



# FEATURES & FUNCTIONS

## FRONT PANEL



### ① DOOR

Open this door when installing print paper or ink sheet. Press ⑬ OPEN button on the top to open the door.

### ② DUST BOX

Holds the paper chips which comes out of the print outlet. Set the dust box to the unit as the figure shows.

#### NOTE

The paper chips may not fall into the dust box sometimes by the setting condition of the unit or the storing condition of print paper.

### ③ PRINT OUTLET

The printed paper comes out here.

### ④ POWER INDICATOR

When the power is turned on, the indicator illuminates.

### ⑤ ALARM INDICATOR

When the unit is overheated, this indicator turns on and off. When the door is open, it illuminates. When other error occurs, it also illuminates. Refer to page 21.

### ⑥ SHEET INDICATOR

When an error concerning ink sheet occurs, this indicator illuminates. Refer to page 21.

### ⑦ PAPER INDICATOR

When an error concerning print paper occurs, this indicator illuminates. Refer to page 21.

### ⑧ DATA INDICATOR

When data is transferring, this indicator turns on and off. Refer to page 21.

### ⑨ FEED & CUT BUTTON

When pressing this button, the print paper is fed and cut. When ⑪ ON LINE indicator is lit, this button is not available. When pressing this button on OFF LINE status with door closed, this unit is initialized. When using this unit for the first time, or whenever the paper is replaced, this button must be pressed.

### ⑩ COPY BUTTON

Press to print the last data which is sent to the unit. When ⑪ ON LINE indicator is lit, this button is not available.

### ⑪ ON LINE BUTTON / ON LINE INDICATOR

Press to switch the PC connection between ON and OFF LINE. When ON LINE is selected, you can control this unit through your PC. When ON LINE is selected, the indicator over this button illuminates. Press again to select OFF LINE(the indicator off). When pressing this button during continuous printing, the printing process will be stopped after completing printing.

### ⑫ INPUT SELECT SWITCH

Switches according to the terminal of connected device. Select one of them before turning on the power.

### ⑬ OPEN BUTTON

Press this button to open the door.

PRECAUTIONS

FEATURES


CONNECTIONS

PREPARATION

TROUBLE-  
SHOOTING

OTHERS

## REAR PANEL



### ① SCSI PORT

Used to connect this printer to a device with SCSI interface such as personal computers. See page 9.

### ② SCSI ID SWITCH

Used to set the SCSI ID number of the connected device. See page 9.

### ③ USB TERMINAL

Used to connect to USB cable.  
For the setting, see page 14.

### ④ PARALLEL DATA IN TERMINAL

Used to connect this printer to a device with PARALLEL DATA interface such as personal computers. When not connecting with a cable, set the provided protective cap. See pages 10-13 for setting.

### ⑤ REMOTE TERMINAL

This terminal is not used.

### ⑥ POWER BUTTON

Use to switch the power ON and OFF.  
Press to turn on power. Press again to turn off power.

### ⑦ POWER SOCKET (AC LINE)

Connects to the provided power cord. Insert the cord firmly.

#### NOTE


Before connecting to mains supply, make sure that the socket-outlet is near the equipment and easily accessible.

## CONNECTION WITH SCSI DATA SIGNAL EQUIPMENT

### CONNECTING TO PERSONAL COMPUTER (EXAMPLE)


Connect this unit to a personal computer as shown below.

Make sure to turn off main power of the unit and other equipment before connection.



**1** Connect the unit and the personal computer with a SCSI cable.

**2** Set the input select switch on the front panel to SCSI.



### SETTING SCSI ID SWITCH



Set the SCSI ID switch on the rear panel according to the personal computer connected.

- Select the ID number among 1 to 6.
- Turn the arrow to set the ID number with a screwdriver.
- The default setting is No. 5.
- No. 7 is provided for personal computer you use and No. 0 is provided for a built-in hard disk.
- Do not set the ID number to the same setting as the connected equipment.



### SETTING TO ON LINE STATUS

**1** Press POWER button on the rear panel to turn on this unit.

**2** Turn on the power of the personal computer connected.

**3** Confirm that the indicator above ON LINE button on the front panel is lit.


- If the indicator is not lit, press ON LINE button to light the indicator.




## CONNECTION WITH PARALLEL DATA SIGNAL EQUIPMENT

### CONNECTING TO PERSONAL COMPUTER (EXAMPLE)

Connect this unit to a personal computer as shown below.  
 Make sure to turn off main power of the unit and other equipment before connection.




- 1 Connect the unit and the personal computer with a parallel cable.
- 2 Set the input select switch on the front panel to PARALLEL.



### SETTING TO ON LINE STATUS

- 1 Press POWER button on the rear panel to turn on this unit.
- 2 Turn on the power of the personal computer connected.



- 3 Confirm that the indicator above ON LINE button on the front panel is lit.
  - If the indicator is not lit, press ON LINE button to light the indicator.




**NOTE**

When setting to “Compatible mode” or “Disable bi-directional support for this printer”, select the SCSI ID switch to “7”.  
 However, if you change the input select switch on the front panel to SCSI, follow “SETTING SCSI ID SWITCH” on Page 9.

## PARALLEL DATA SIGNAL ALLOCATION

- Connector ..... JD36SL equivalent (36-pin)
- Input level ..... TTL
- Parallel input connector terminal Signal allocation (Signal : Compatible)



Pin No.	Return pin No.	Signal	From/To	Function
1	19	$\overline{\text{STROBE}}$	PC/DP	Strobe pulse for data reading. Incoming pulse width should be 0.5 $\mu$ s minimum. At regular conditions, "High" data will be read after becoming "Low".
2	20	DATA1(LSB)	PC/DP	Information will be expressed for parallel data of every signal from bit No.1 to No.8.
3	21	DATA2	PC/DP	
4	22	DATA3	PC/DP	
5	23	DATA4	PC/DP	
6	24	DATA5	PC/DP	
7	25	DATA6	PC/DP	
8	26	DATA7	PC/DP	
9	27	DATA8(MSB)	PC/DP	
10	28	$\overline{\text{ACK}}$ (ACKNOWLEDGE)	DP/PC	
11	29	BUSY	DP/PC	High: DP data is not accepted. Low: DP data is accepted. The signal becomes "High" in the following cases: • On OFF LINE entry • During data entry
12		P•E (PAPER END)	DP/PC	High: No paper Low: Paper available
13		SELECT	DP/PC	High: When ON LINE switch is ON Low: When ON LINE switch is OFF
14		AutoFd	PC/DP	High
16•17		GND		Earth
18		High	DP/PC	PeripheralLogicHigh
19 - 30		GND		Earth
31	16	$\overline{\text{Init}}$	PC/DP	Clears sending data to this unit. (Low) Incoming pulse width should be 100 $\mu$ s minimum.
32		$\overline{\text{Fault}}$	DP/PC	Low: Abnormal condition occurs in DP. (e.g. error)
15• 33 - 35		NC		Unused
36		$\overline{\text{SelectIn}}$	PC/DP	Low

PRECAUTIONS

FEATURES

CONNECTIONS

PREPARATION

TROUBLE-  
SHOOTING

OTHERS

## CONNECTIONS

- Parallel input connector terminal Signal allocation (Signal : Nibble)

Pin No.	Return pin No.	Signal	From/To	Function
1	19	HostClk	PC/DP	High
2 - 9	20 - 27	Unknown	PC/DP	Unknown
10	28	PtrBusy	DP/PC	Sends data in "Low" when HostBusy is "Low". After HostBusy turns "High", this signal becomes "High".
11	29	PtrBusy	DP/PC	Data4, Data8(MSB)
12		AckDataReq	DP/PC	Data3, Data7
13		Xflag	DP/PC	Data2, Data6
14		HostBusy	PC/DP	High: DP is on BUSY status. Low: DP can send data.
16•17		GND		Earth
18		High	DP/PC	PeripheralLogicHigh
19 - 30		GND		Earth
31	16	$\overline{\text{Init}}$	PC/DP	Clears sending data to this unit. (Low) Incoming pulse width should be 100 $\mu$ s minimum.
32		$\overline{\text{DataAvail}}$	DP/PC	Data1(LSB), Data5
15• 33 - 35		NC		Unused
36		1284 Active	PC/DP	Becomes "High" when DP requests each mode of IEEE1284.

- Parallel input connector terminal Signal allocation (Signal : ECP)


Pin No.	Return pin No.	Signal	From/To	Function
1	19	HostClk	PC/DP	Forward data transfer : Becomes "Low" when PeriphAck is "Low" and there is data to be read. Returns to "High" when PeriphAck becomes "High".
2	20	DATA1(LSB)	PC/DP	High: data 1 Low: data 0  Information will be expressed for parallel data of every signal from bit No.1 to No.8.
3	21	DATA2	PC/DP	
4	22	DATA3	PC/DP	
5	23	DATA4	PC/DP	
6	24	DATA5	PC/DP	
7	25	DATA6	PC/DP	
8	26	DATA7	PC/DP	
9	27	DATA8(MSB)	PC/DP	
10	28	PeriphClk	DP/PC	
11	29	PeriphAck	DP/PC	Forward data transfer: High: DP is on BUSY status. Low: DP can accept data.
12		AckReverse	DP/PC	High: Forward data transfer (Receive) Low: Reverse data transfer (Send)
13		Xflag	DP/PC	High: During supporting ECP mode
14		HostAck	PC/DP	Reverse data transfer: High: PC is on BUSY status. Low: PC can send data.
16•17		GND		Earth
18		High	DP/PC	PeripheralLogicHigh
19 - 30		GND		Earth
31	16	Reverse Request	PC/DP	Low : When PC requests DP to send data
32		Periph Request	DP/PC	Low : When DP requests PC to send data
15• 33 - 35		NC		Unused
36		1284 Active	PC/DP	Becomes "High" when DP requests each mode of IEEE1284.

PRECAUTIONS  
FEATURES  
CONNECTIONS  
PREPARATION  
TROUBLE-SHOOTING  
OTHERS


## CONNECTION WITH USB DATA SIGNAL EQUIPMENT

### CONNECTING TO PERSONAL COMPUTER (EXAMPLE)

Connect this unit to a personal computer as shown below.




- 1 Connect the unit and the personal computer with a USB cable.
- 2 Set the input select switch on the front panel to USB.



### SETTING TO ON LINE STATUS

- 1 Press the POWER button on the rear panel to turn on this unit.
- 2 Turn on the power of the personal computer connected.



- 3 Confirm that the indicator above ON LINE button on the front panel is lit.
  - If the indicator is not lit, press ON LINE button to light the indicator.



# BEFORE OPERATION

Before printing,

- 1 Install ink sheet to this unit. (pages 15-16)
- 2 Install print paper to this unit. (page 17-18)

## PRINT PAPER AND INK SHEET

When using this unit for printing, make sure to use the following types of paper and ink sheet set.

### PRINT PAPER AND INK SHEET


Product name	Print size	No. of prints	Usage
CK8000FM4P	M size	240	surface-laminated color print
CK8000FL4P	L size	220	surface-laminated color print
CK8000FX4P	X size	110	surface-laminated color print
CK8000FW4P	W size	110	surface-laminated color print
CK8000PSTE	L size	220	surface-laminated color print for post card

## INSTALLATION OF INK SHEET

### INSTALLING THE INK SHEET

1 Set the ink sheet to the ink cassette as shown right.

- Make sure to set them in the correct position.
- IC chip with the IC holder is attached to the ink sheet.  
Set the IC holder to the ink cassette as shown below.




#### NOTE

- Place the ink cassette on the flat surface, and set the ink sheet in it.
- Make sure to set the ink sheet rollers to the ink cassette firmly.
- Do not remove the IC chip or IC holder from the ink sheet. Removal of the IC chip or IC holder will stop the unit from functioning correctly.

# BEFORE OPERATION

## ■ INSTALLING THE INK CASSETTE


1 Press OPEN button to open the door.



2 Set the ink cassette with ink sheet into the compartment of the unit.


Make sure to set the green roller which ink sheet has not rolled yet to the front. Then set the ink sheet and cassette into the position of the unit which marked in the figure.

Make sure to set the ivory ink sheet roller to the ditches firmly.  
Turn the green roller to eliminate any slack.




3 Push up the ink cassette as the arrow shows until you hear the click.

Make sure to set the green ink sheet roller to the ditches which the arrows point firmly.



### NOTE

If the ink sheet is used up, take out the print paper first. Then retrace the steps 1 to 3 to change the print paper and ink sheet.



## INSTALLATION OF PRINT PAPER

After setting the ink cassette, install the print paper to the unit.  
Do not install the print paper without setting the ink cassette.


### 1 Put the supplied paper attachments to both sides of the print paper.

Put the orange paper attachment without gear to the left side of the print paper. Then put the blue paper attachment with gear to the right side of the print paper. Attach the paper attachments firmly aligning the tabs of the attachments with the slits in the paper bobbins.

#### NOTE

- Make sure to put them to the correct position.
- Do not remove the sticker on the print paper yet.
- Do not slacken the paper. Any slacks of the print paper may degrade print quality.

Set Spacer-M when using  
CK8000FM4P or CK8000FX4P  
as shown right.



#### NOTE





Do not touch the thermal head.  
Fingerprints or dust on the thermal head will degrade the print quality.

### 2 Set the print paper to the unit.

When installing the print paper, make sure to turn on the power of this unit.  
Make sure to set the print paper firmly.

#### NOTE

Install the print paper into the unit carefully. If you drop it to the upper end of the ditch, this or accessories may be damaged.



PRECAUTIONS

FEATURES

CONNECTIONS

PREPARATION

TROUBLE-  
SHOOTING

OTHERS

## BEFORE OPERATION

### 3 Remove the sticker, and insert the print paper between rollers as shown right.

- Remove the sticker before inserting print paper between rollers. Make sure to insert the paper straight.
- Send the print paper under the roller until LED lamp illuminates.

#### NOTE

- Keep the roller away from dirt. The dirt of the roller may degrade the print quality.

### 4 When LED lamp illuminates, press PAPER INSTALLATION button.

The print paper is pinned temporary.

(Every time pressing this button, ON/OFF of this function switches.)

#### NOTE

- When print paper is used up (PAPER indicator illuminates.), take out the ink cassette first. Then retrace the above steps 1 to 3 to replace print paper.
- Make sure to turn on the power when changing print paper.
- Make sure to eliminate any slack of print paper. Operating the following steps with slack paper, the print paper may be damaged.

### 5 Close the door.

#### NOTE

- When closing the door, push it until a click is heard.
- If SHEET indicator illuminates when closing the door, IC chip may not be installed, or not set correctly.  
In this case, open the door to make sure that IC chip is set correctly. Then close the door again.
- Print paper setting will be initialized two seconds after closing door. Go on to the next step after completing initializing.

### 6 Press ON LINE button to change to OFF LINE status. (The indicator does not illuminate.)

### 7 Press FEED & CUT button.

The print paper is cut after feeding about 15 cm. Repeat this step 3 times when replacing print paper.





(This step is for initializing, and helps to remove finger prints and dust on the print paper. it also initializes before printing.)

### 8 Press ON LINE button to turn on the indicator.

The installation of print paper and ink sheet is completed.

#### NOTE

- Make sure to replace the ink sheet and print paper at the same time.
- When replacing them, throw away the paper chips in the dust box.
- An IC is built in the ink sheet. This is the IC chip, not a battery. This IC can be thrown away as normal waste.



## USAGE AND KEEPING OF PAPER SHEET SET

PRECAUTIONS

FEATURES

CONNECTIONS

PREPARATION

TROUBLE-  
SHOOTING

OTHERS

### BEFORE PRINTING

- Fingerprints or dust on the paper's printing surface may degrade print quality and cause paper jams. When not cutting the paper by FEED & CUT procedure while replacing the print paper, 2 or 3 images may be printed with a blank part due to hand's dust or oil.
- When print paper is rapidly transferred from a cool place to a hot place, vapor or dew is generated on the paper's surface causing paper jams or degraded print quality. Leave the print paper in the room to stabilize its temperature before using it.
- If FEED & CUT procedure is repeated while installing the print paper, the indicated number of prints may not be done. Replacing the print paper before it is used up, the indicated number of prints may also not be done.
- Do not put or store the print paper in a upright position. It may cause some slack, and the print paper may get out of shape.

### AFTER PRINTING AND STORAGE

Surface-laminated print paper which is durable and keeps picture quality is suitable for this unit.

### AFTER PRINTING

- When the printed paper is touched by a wet hand, the print may be discolored.
- If the paper absorbs nonvolatile organic solvents (alcohol, ester, ketone etc.) the print may be discolored.
- Discoloration of prints will be accelerated if the print paper comes into contact with soft vinyl chloride such as transparent tape, etc.
- Avoid storing prints in direct sunlight or places with high humidity.

### STORAGE

- Leaving the print paper in contact with PVC- based materials causes color of print paper to come off and to be stained.
- Never store print paper in places that are close to heater, or in direct sunlight.

Keep print paper in a place where;

Temperature : 5 - 30 °C

Humidity : 20 - 60 %RH

**INSTALLATION PRINTER DRIVER**

- It is necessary to install a printer driver to print the data from the personal computer connected with this unit.  
The printer drivers which start up Windows® or Windows NT® are supplied with this unit.

Product name	Operating system conditions
CPD8000W	Applies for Windows® 95, Windows®98, or Windows® Millennium operation system
CPD8000N	Applies for Microsoft®WindowsNT® 4.0 operating system
CPD8000N0	Applies for Microsoft®Windows 2000 operating system

- Refer to the operation manual “ReadMe” of the driver software for installation of the printer driver.
- Microsoft®Windows®, Windows NT®, Windows 2000 and Windows® Millennium are the registered trademarks of the Microsoft Corporation.

# ERROR MESSAGES & COUNTERMEASURES

## INDICATION ON THE FRONT PANEL AND COUNTERMEASURES

■ If for some reason, printing is not possible or error occurs during printing, the indicator on the front panel will be illuminated or lit on and off.

In this case, follow the procedure described below.

○: lit    ●: not lit    ○●: lit on and off    — : depends on the previous condition

ALARM	SHEET	PAPER	DATA	Causes and Countermeasures	Page
○	—	—	—	The door is open. • Close the door.	7
○● (Slow)	—	—	—	The temperature of the thermal head becomes too high. • Wait until the indication goes off. * Note 1	---
●	○	—	—	Ink sheet is not set. Ink sheet is used up. • Replace the ink sheet with a new one.	15-16
●	○● (Slow)	—	—	Alarm for the ink sheet remainings * Note 2 • The remains of the ink sheet become the setting number.	---
●	—	○	—	Print paper is used up. • Install new print paper.	17-18
●	○	○	—	Ink sheet and print paper are not a correct set. • Use a correct set of ink sheet and print paper.	15-18
○● (Fast)	●	●	—	Paper jamming occurs. • Refer to "Overcoming paper jams".	22
○	○● (Slow)	—	—	IC chip error The IC chip in ink sheet is not a specified one. • Set the specified IC chip.	15
○● (Slow)	○● (Slow)	—	—	Ink sheet distinction error IC chip and the ink sheet are not a correct set. • Set the specified ink sheet.	15
○	○	—	—	Ink sheet mark error Ink sheet is not installed correctly. • Re-Install the ink sheet correctly. When the printing process is interrupted, press FEED & CUT button after confirming the indicator above ON LINE button is off.	15-18

\*Note 1 When setting the continuous printing, the continuous printing is carried out again after the error indication goes off.

\*Note 2 During printing, the error indication may not illuminate.

PRECAUTIONS

FEATURES

CONNECTIONS

PREPARATION


TROUBLE-SHOOTING

OTHERS

## OVERCOMING PAPER JAMS


### 1 Press OPEN button to open the door.

Make sure that the unit is powered ON when opening the door.  
When it is not working, turn off the power once. Then press OPEN button again.




### 2 Remove the ink cassette.

Push down the ink cassette as shown by an arrow ① and pull it out.




### 3 Take out the print paper.



### 4 Cut the defective part of print paper with scissors.

#### NOTE


Make sure to cut the printed part of paper. When printing an image on the printed paper overlapped, the ink sheet may stick on the print paper and ink sheet may be cut.



### 5 Install the print paper and ink cassette with the ink sheet. (Refer to page 15-18.)

### 6 On OFF LINE status, press FEED & CUT button.

The setting of this unit is initialized.



## BEFORE CALLING FOR SERVICE

For the following symptoms, check the unit again.

Symptom	Check & Remedy
No power	Is the power cord plug disconnected from the outlet? → Connect the power cord plug to the outlet firmly. → The protective circuit may work. Turn off the power and wait for about 2 minutes. Then turn on the power again.
The image is not printed.	Is the image data sent to this unit? → Confirm that the image data is sent to this unit. Is the print paper or ink sheet used up? → Check the status. Is the ink cassette set correctly? → Set the ink cassette correctly. Is the IC chip set correctly? → Set the IC chip correctly.
The image cannot be printed to the possible print area.	Is the printer driver set correctly? → Check the status of the printer driver.
The image can not be transferred.	Is the ON LINE indicator lit? → Check the status. Is the input select switch set correctly? → Check the setting.
COPY button does not work.	Is the ON LINE indicator lit? → Turn off the indicator. Is the image data transferred? → Check the status.
The personal computer does not recognize this unit.	Is this unit on OFF LINE status? → Press ON LINE button to be on ON LINE status. Is the SCSI ID number duplicate with another equipment? → Change the SCSI ID number. Is the input select switch set correctly? → Check the setting.

PRECAUTIONS

FEATURES

CONNECTIONS

PREPARATION

TROUBLE-SHOOTING

OTHERS

## ASSIGNMENT OF TRANSPORTATION PACKAGE

When transporting this unit for some reasons such as repairing, remain the following condition.

### Use genuine package unit

Genuine package unit is prepared as a optional parts.

Using of the genuine package more than one round trip can not be guaranteed.

Purchase another package unit when transporting this units again.

Remove all the accessories from the unit.

# CLEANING

Cleaning as indicated below will help maintain stable printer operation and extend the printer's life.

## Preparations

- Alcohol (isopropyl alcohol)
- Tissue paper (Fold in half about 4 times, and use the folded side to clean.)
- Cotton buds
- Damped cloth or adhesive tape

Other : Cleaner pen (Option)\*  
 \* Please ask the dealer about options.

Make sure to turn off the power before cleaning.

**1 Press OPEN button to open the door.**

**2 Remove the ink cassette.**

**3 Take out the print paper.**

**4 Clean the ink sheet sensor.**

Wipe the circled part in the right figure.  
 Wipe the dust gently with cotton buds etc. which are soaked in a small amount of alcohol.

**5 Clean the head.**


Clean the part below the thermal head which develops heat.  
 Wipe the head cleaning part carefully with tissue paper etc. which is soaked in a small amount of alcohol.

### NOTE


- Do not damage the thermal head.
- When the symptom of the poor print quality is not corrected even if the head is cleaned, replacing the thermal head is required. Contact your dealer.
- Thermal head is hot right after printing. Wait until the head temperature is low when cleaning the thermal head.

**6 Clean the paper attachments.**





Clean the parts which are the print paper sides as shown right.  
 Wipe the head cleaning part carefully with tissue paper etc. which is soaked in a small amount of alcohol.



How to fold tissue paper



Cleaner pen



# SPEC & OPTIONS

## SPECIFICATIONS

Class	Digital Color Printer	
Model	CP8000DW	
Printing method	Sublimation Dye Thermal Transfer line print 3 color faces progressive printing (yellow, magenta and cyan) and surface lamination	
Print's resolution	304 x 304 PPI (Pixel per inch)	
Dot resolution	M size	1592x1112 pixels (without frame)
	L size	1892x1268 pixels (without frame)
	X size	1592x2176 pixels (without frame)
	W size	1892x2788 pixels (without frame)
Gradations	256 (8 bits) for each color (About 16.7 million colors)	
Printing time	M size : Approx. 15 sec./sheet (ID mode : Approx. 29 s) L size : Approx. 22 sec./sheet (ID mode : Approx. 32 s) X size : Approx. 28 sec./sheet (ID mode : Approx. 50 s) W size : Approx. 40 sec./sheet (ID mode : Approx. 62 s)	
Ink-sheet	Special cartridge method	
Print paper	Special roll paper	Printing area
	M size 127 x 89mm	127 x 89mm (max.) without frame
	L size 152 x 102mm	152 x 102mm (max.) without frame
	X size 127 x 178mm	127 x 178mm (max.) without frame
	W size 152 x 229mm	152 x 229mm (max.) without frame
Supply method	Automatic	
Interface	SCSI -II(Micro mini 50 pin), IEEE1284, USB	
Power supply	AC 220-240 V 50/60Hz, AC 120V 50/60Hz	
Power consumption	1.3 A (AC220 - 240 V, 50/60 Hz), 2.5 A (AC120 V, 50/60 Hz) during printing 0.2 A (AC220 - 240 V, 50/60 Hz), 0.2 A (AC120 V, 50/60 Hz) when not printing	
Operating conditions	Temperature : 5°C - 40°C Humidity : 20 - 80% (no dewing)	
Installation conditions	Operating attitude : Horizontal $\pm 5^\circ$	
Outside dimensions	330(W) x 360(D) x 270(H) mm	
Weight	14 kg	
Standard accessories	Power cords (for 120V and 220V), Ink cassette (1), Operation manual(1), SCSI Terminator(1), Printer driver software (CPD8000W, CPD8000N, CPD8000N0), Paper attachments(2), Dust box (1), Spacer-M (2)	

PRECAUTIONS

FEATURES

CONNECTIONS

PREPARATION

TROUBLE-SHOOTING

OTHERS

## OPTIONS

### PRINT PAPER AND INK SHEET

Product name	Print size	No. of prints	Usage
CK8000FM4P	M size	240	Surface-laminated color print
CK8000FL4P	L size	220	Surface-laminated color print
CK8000FX4P	X size	110	Surface-laminated color print
CK8000FW4P	W size	110	Surface-laminated color print
CK8000PSTE	L size	220	Surface-laminated color print for post card



**MITSUBISHI DIGITAL ELECTRONICS AMERICA, INC.**

9351 Jeronimo Road, Irvine, CA 92618, U.S.A.

Phone 949-465-6000

**Mitsubishi Electric Europe B.V.**

**UK Branch**

Travellers Lane, Hatfield, Herts. AL10 8XB, England, U.K.

Phone (1) 707 276100 FAX (1) 707 278755

**German Branch**

Gothaer Strasse 8, Postfach 1548, 40880 Ratingen 1, Germany

Phone (2102) 4860 FAX (2102) 486-732

**French Branch**

25, Boulevard des Bouvets - 92741 NANTERRE cedex

Phone (01) 55.68.55.00 FAX (01) 55.68.57.31

**Italian Branch**

Centro Direzionale Colleoni, Palazzo Perseo-Ingresso 2,

Via Paracelso 12, 20041 Agrate Brianza, (Milano) Italy

Phone (039) 60531 FAX (039) 6057694

**Benelux Branch**

Nijverheidsweg 23 A, 3641 RP. Postbus 222, 3640 AE Mijdrecht

Phone 02972-82461 FAX 02972-83936

**Spanish Branch (Barcelona)**

Sucursal en españa

Polígono Industrial "Can Magí", Calle Joan Bucallà 2-4,

Apartado de Correos 420, 08190 Sant Cugat del Vallès,

Barcelona, Spain

Phone 93.5653154 FAX 93.5894388