
FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1). This device may not cause harmful interference, and
- (2). This device must accept any interference received, including interference that may cause undesired operation.

Note:

This equipment has been tested and found to comply with the limits for Class B digital devices, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected

Use of shielded cable is required to comply with Class B limits in Subpart B of Part 15 of the FCC rules.

Do not make any changes or modifications to the equipment unless otherwise specified in the manual. If such changes or modifications should be made, you could be required to stop operation of the equipment.

Product Information

1. Product design and specifications are subject to change without notice. This includes primary product specifications, software, software drivers, and user's manual. This User Manual is a general reference guide for the product.

2. The product and accessories that come with your camera may be different from those described in this manual. This is due to the fact that different retailers often specify slightly different product inclusions and accessories to suit their market requirements, customer demographics, and geographical preferences. Products very often vary between retailers especially with accessories such as batteries, chargers, AC adapters, memory cards, cables, carrying cases/pouches, and language support. Occasionally a retailer will specify a unique product color, appearance, and internal memory capacity. Contact your dealer for precise product definition and included accessories.
3. The illustrations in this manual are for the purpose of explanation and may differ from the actual design of your camera.
4. The manufacturer assumes no liability for any errors or discrepancies in this user manual.
5. For driver updates, you can check the "Download" section of our website, www.geniusnet.com.tw.

SAFETY INSTRUCTIONS

Read and understand all **Warnings** and **Cautions** before using this product.

Warnings

- **If foreign objects or water have entered the camera, turn the power OFF and remove the batteries and the AC power adapter.**

Continued use in this state might cause fire or electric shock. Consult the store of purchase.



- **If the camera has fallen or its case has been damaged, turn the power OFF and remove the batteries and the AC power adapter.**

Continued use in this state might cause fire or electric shock. Consult the store of purchase.



- **Do not disassemble, change or repair the camera.**

This might cause fire or electric shock. For repair or internal inspection, ask the store of purchase.



- **Use the supplied AC adapter only with the indicated power supply voltage.**

Use with any other power supply voltage might cause fire or electric shock.



■ **Do not use the camera in areas near water.**

This might cause fire or electric shock. Take special care during rain, snow, on the beach, or near the shore.



■ **Do not place the camera on inclined or unstable surfaces.**

This might cause the camera to fall or tilt over, causing injury.



■ **Keep the batteries out of the reach of children.**

Swallowing batteries might cause poisoning. If the battery is accidentally swallowed, immediately consult a physician.



■ **Do not use the camera while you are walking, driving or riding a motorcycle.**

This might cause you to fall over or result in traffic accident.



Cautions

■ **Insert the batteries paying careful attention to the polarity (+ or –) of the terminals.**

Inserting the batteries with its polarities inverted might cause fire and injury, or damage to the surrounding areas due to the battery rupturing or leaking.



■ **Do not fire the flash close to anyone's eyes.**

This might cause damage to the person's eyesight.



■ **Do not subject the LCD monitor to impact.**

This might damage the glass on the screen or cause the internal fluid to leak. If the internal fluid enters your eyes or comes into contact with your body or clothes, rinse with fresh water.
If the internal fluid has entered your eyes, consult a physician to receive treatment.



■ **A camera is a precision instrument. Do not drop it, strike it or use excessive force when handling the camera.**

This might cause damage to the camera.



■ **Do not use the camera in humid, steamy, smoky, or dusty places.**

This might cause fire or electric shock.



■ **Do not remove the battery immediately after long period of continuous use.**

The battery becomes hot during use. Touching a hot battery might cause burns.



- **Do not wrap the camera or place it in cloth or blankets.**

This might cause heat to build up and deform the case, resulting in fire. ☹
Use the camera in a well-ventilated place.

- **Do not leave the camera in places where the temperature may rise significantly, such as inside a car.**

This might adversely affect the case or the parts inside, resulting in fire. ☹

- **Before you move the camera, disconnect cords and cables.**

Failure to do this might damage cords and cables, resulting in fire and electric shock. ☹

Notes on Battery Usage

When you use the battery, carefully read and strictly observe the **Safety Instructions** and the notes described below:

- Different battery types and surrounding temperatures may affect the battery performance.
- Avoid using batteries in extremely cold environments as low temperatures can shorten the battery life and reduce camera performance.
- If you are using the new rechargeable battery or rechargeable battery that has not been used for an extended period of time (batteries that pass the expiry date are exceptions) might affect the number of pictures that can be taken. Therefore, to maximize their performance and lifetime, we recommend that you fully charge the batteries and discharge them for at least one complete cycle before use.
- The battery may feel warm when using the camera for an extended period of time or using the flash continuously. This is normal and not a malfunction.
- The camera may feel warm when being used continuously or for an extended period of time. This is normal and not a malfunction.
- If you will not be using the batteries for an extended period of time, remove them from the camera to prevent leakage or corrosion.
- Always keep the terminals in a clean state.
- Never use manganese batteries.
- Risk of explosion if battery is replaced by an incorrect type.
- Dispose of used batteries according to the instructions.

CONTENTS

INTRODUCTION 8-9

Overview
Package contents

GETTING TO KNOW THE

CAMERA 10-14

Front view
Rear view
Mode Dial
LCD monitor information

PREPARING THE

CAMERA 14-17

Inserting the Battery
Using the AC Power Adapter (optional accessory)
Inserting and Removing an SD Memory Card
Attaching the Camera Strap

GETTING STARTED 17-20

Turning the Power On/Off
Choosing the Screen Language
Setting the Date and Time
Formatting an SD Memory Card or Internal Memory
Using the LCD Monitor

PHOTOGRAPHY MODE 20-26

Shooting Images-The Basics
Setting Image Resolution and Quality
Using the Zoom Function

Using the Flash
Using the Self-Timer
Adjusting the Exposure (EV Compensation)
Setting White Balance

USING THE MODE DIAL ... 26-29

Auto Mode
Program Mode
Portrait Mode
Landscape Mode
Sports Mode
Night Mode

ADVANCED SHOOTING .. 30-32

Burst
Auto Exposure Bracketing
Selecting the Metering Mode

PLAY MODE

— THE BASIC 32-36

Viewing Images
Magnifying Images
Thumbnail Display (Index Playback)
Slideshow Display
Resizing an Image

MOVIE MODE 36-37

Recording Video Clips
Playing Back Video Clips

PLAY MODE—ADVANCED

FUNCTIONS 38-48

Playing Back Images/Video Clips on TV

Deleting Images/Video Clips
Protecting Images/Video Clips
Setting the DPOF
Connecting to a PictBridge Compliant
Printer

(same as USB driver)
Step 2: Connecting the digital still Camera
to your computer
Step 3: Run your application software (i.e.
Windows NetMeeting)

**TRANSFERRING FILES
FROM YOUR DIGITAL STILL**

**CAMERA TO
COMPUTER.....48-50**

Step 1: Installing the USB Driver (Windows
98/98SE users only)
Step 2: Connecting the digital still Camera
to your computer
Step 3: Downloading Images, video clips
or voice recording files

**EDITING SOFTWARE
INSTALLATION.....50-51**

Installing Photo Explorer
Installing Photo Express

USING THE DIGITAL STILL

**CAMERA AS A
PC CAMERA.....52-54**

Step 1: Installing the PC camera Driver

MENU OPTIONS.....54-63

Camera Menu
Video Menu
Play Menu
Setup Menu

**CONNECTING YOUR
CAMERA TO OTHER
DEVICES.....64**

SPECIFICATIONS.....65-66

APPENDIX.....66-68
Troubleshooting Guide
Possible Number of Recordable Image
Approximate Duration of Recording Time

INTRODUCTION

Overview

Thank you for purchasing the new digital still camera!

Equipped with a 5.0 Mega pixels CCD sensor, your camera delivers good quality, 2560 x 1920 resolution images.

Other features provided by the camera include the following:

- **5.0 Mega pixels**

A high-resolution CCD sensor provides 5.0 mega pixels for good quality of images.

- **USB connection (USB 1.1 compliant)**

Still images, video clips, or voice recording files that you have recorded can be downloaded to your computer using the USB cable (A USB driver is required for Win 98 and Win98SE).

- **Auto flash**

An auto flash sensor automatically detects the shooting (lightening) conditions and determines whether the flash should be used.

- **1.8" LTPS color image LCD monitor**

- **Optical zoom:** 1x~3x

- **Digital zoom:** 1x~4x

- **12MB internal (built-in) memory**

Images can be captured without using a memory card.

- **DPOF functionality**

DPOF can be used to print your images on a DPOF compatible printer by simply inserting the memory card.

- **PictBridge support**

You can connect the camera directly to a printer that supports PictBridge and perform image selection and printing using the camera monitor screen and controls.

- **Support for SD memory card for memory expansion**

You may wish to expand the memory capacity (up to 512MB capacity) by using an external memory card.

■ **Provided editing software: Photo Explorer / Photo Express**

You can enhance and retouch your images on your computer by using the provided editing software.

Package contents

Carefully unpack your package and make sure that you have the following items. In the event that any item is missing or if you find any mismatch or damage, promptly contact your dealer.

- | | |
|------------------------|-------------------|
| ■ Digital still camera | ■ USB cable |
| ■ AV cable | ■ Software CD-ROM |
| ■ User's manual | ■ Camera strap |
| ■ Quick guide | ■ Camera pouch |
| ■ AA x 2 Batteries | |




NOTE

- Accessory and components may vary by different retailer.

GETTING TO KNOW THE CAMERA


Front view




1. Shutter button
2. Flash
3. Microphone
4. Lens
5. Power button
6. Mode dial
7. Self-timer LED
8. Viewfinder window
9. PC (USB) / AV Out terminal
10. DC in 3V terminal



Rear view


1. Viewfinder
2. Rec-play button
3. Menu button
4. Delete button
5. OK / (Display) button
6. Tripod socket
7. / Zoom out (wide-angle) button
8. Thumbnail button
9. / Zoom in (telephoto) button
10. LCD monitor
11. Arrow button (Up)
12. Arrow button (Right)
13. Self-timer button












12.  Arrow button (Down)
13.  Arrow button (Left)
-  Flash button
14. Battery / SD card cover

Mode Dial

You can select from seven shooting modes and setup mode according to shooting conditions to achieve the desired effect.




	Mode	Description
1.		Power button Press to turn on/off the power.
2.		Program Select this mode to permit the shutter speed and aperture to be set manually.
3.		Auto Select this mode to adjust point-and-shoot action.
4.		Video Select this mode to record video clips.
5.		Portrait Select this mode to make people stand out with the background out-of-focus.
6.		Landscape Use this mode to take photographs of distant scenery or landscapes.
7.		Sports Use this mode to shoot fast moving objects.







- | | | | |
|----|---|-------|--|
| 8. |  | Night | Select this option to take photographs of people against a dusk or nighttime background. |
| 9. |  | Setup | Select this mode to adjust the camera settings. |

LCD Monitor Information

■ Camera Mode



1. Mode indication

- [**A**] Auto Mode
- [] Setup Mode
- [] Video Mode
- [] Landscape Mode
- [**P**] Program Mode
- [] Sports Mode
- [] Portrait Mode
- [] Night Mode

2. Image quality



- [] FINE
- [] NORMAL
- [] ECONOMY

3. Image size




- [**5M**] 2560 x 1920
- [**3M**] 2048 x 1536
- [**1.2M**] 1280 x 960
- [**0.3M**] 640 x 480


4. Possible number of shots

5. Internal memory/SD memory card indicator

- [] Status of internal memory
- [] Status of SD memory card


6. Remaining battery status


- [] Full battery power
- [] Medium battery power
- [] Low battery power


[] No battery power

7. Self-timer mode

[] OFF

[] 2 sec. delay

[] 10 sec. delay

[] 10+2 sec. delay

8. White balance

AUTO

[] DAYLIGHT


[] CLOUDY

[] SUNSET

[] TUNGSTEN

[] FLUORESCENT

9. Capture mode indicator

[] SINGLE

[] BURST

[] AEB

10. Date

11. Zoom stat

12. Focus area

13. Focus indicator


(no indication for auto focus)

AUTO


[] MACRO


[] INFINITY

14. Flash mode

[] Auto Flash (Default)

[] Red Eye

[] Forced flash

[] No Flash

Video mode

1. Video mode

2. Recordable movie time available

3. SD memory card indicator (if present)

4. Battery power indicator

5. Focus area




Image Playback

1. Playback mode
2. SD memory card indicator (if present)
3. Battery power indicator
4. Playback information



Video Playback

1. Playback mode
2. Video mode
3. SD memory card indicator (if present)
4. Battery power indicator
5. Playback indicator
6. Playback information




PREPARING THE CAMERA

Installing the Battery

You can use 2 AA size batteries to turn on the camera. Make sure that the power of the digital camera is off before inserting or removing the batteries.

1. Make sure the camera is turned off.
2. Open the battery cover.
3. Insert the batteries in the correct orientation as shown in the illustration.



4. Close the battery cover.

- To remove the batteries, turn the camera off before removing batteries and hold the camera with the battery cover facing upward, then open the battery cover.




NOTE

- Be careful not to drop the batteries when opening or closing the battery cover.

Using the AC Power Adapter (Optional Accessory)

Use of the AC power adapter is recommended if you intend to use the LCD monitor for a long time or connect the camera to a PC.

1. Make sure your camera is turned off.
2. Connect one end of the AC power adapter to the camera jack labeled "DC IN 3.0V".
3. Connect the other end to an electrical outlet.




NOTE

- Make sure to use only the AC power adapter specified for the camera. Damage caused by the use of an incorrect adapter is not covered under the warranty.
- To prevent unexpected auto power off resulting from no battery power left during the process of transferring your images to the computer; use the AC power adapter as a power supply.
- The AC power adapter can only be used to power the camera. Batteries cannot be charged inside the camera.

Inserting and Removing an SD Memory Card (Optional Accessory)


The digital camera comes with 12MB of internal memory, allowing you to store captured still images or video clips in the digital camera. However, you can also expand the memory capacity by using an optional SD (Secure Digital) memory card so that you can store more files.

1. Make sure your camera is turned off before inserting or removing a memory card.
2. Open the SD memory card cover.
3. Insert an SD memory card in the correct orientation as shown in the illustration.
4. Close the battery/SD memory card cover.
 - To remove the SD memory card, make sure the camera is turned off. Press lightly on the edge of the memory card and it will eject.




NOTE

- Be sure to format an SD memory card with this digital still camera before using it. Refer to section in the manual titled “**Formatting an SD Memory Card or Internal Memory**” for further details.
- To prevent valuable data from being accidentally erased from an SD card, you can slide the write protect tab (on the side of the SD memory card) to “LOCK”.
- To save, edit, or erase data on an SD memory card, you must unlock the card.



Attaching the Camera Strap

Attach the strap as shown in the illustration.






LED Indicators

Indicator	State	Description/Activity
LED indicator	Solid red	The digital camera is powering up.
	Solid green	The digital camera is ready to record images (or movies).
LED indicator	Blinking green	USB communication/transfer in progress
LED indicator	Blinking red	Charging the flash.
Self-timer indicator	Blinking red	The self-timer function is activated.

GETTING STARTED



Turning the Power On/Off







1. Press the  button until the digital still camera turns on.
2. To turn the power off, press and hold the  button again.



Choosing the Screen Language

When the camera is turned on for the first time, a language-selection screen will be displayed in the monitor. Follow the steps below to choose the desired language.











1. Rotate the mode dial to  and turn your camera on by pressing the  button.



2. Press  to select the [CUSTOM] menu.
3. Use  to select [LANGUAGE], and then press the  button.
4. Use  or  to select the language you want.
5. Press the  button to confirm.




Setting the Date and Time

Follow the steps below to set the date display style, current date and time.





1. Rotate the mode dial to  and turn your camera on by pressing the  button.
2. Press  to select the [CUSTOM] menu.
3. Use  to select [DATE & TIME], then press the  button.
 - You may press  or  to switch the date types.
4. Press the  /  buttons to select Year, Month, Day and Time fields.
 - To increase a value, press the  button.




- To decrease a value, slide the zoom lever to the ▼ button.
 - The time is displayed in 24-hours format.
5. Press the  button after all fields are set.

Formatting an SD Memory Card or Internal Memory

The term “Formatting” means preparing an “SD Memory Card” to record images; this process is also called “initialization”. This utility formats the internal memory (or memory card) and erases all stored images and data.

1. Rotate the mode dial to  and turn your camera on by pressing the  button.
 - The [BASIC] menu is displayed.
2. Use ▼ to select [FORMAT], then press the  button.
3. Use ▲ or ▼ to select [YES], then press the  button to confirm.










NOTE

- When you format an SD memory card, be aware that all data of which will be permanently erased. Protected images are also erased.
- To format the internal memory, do not insert a memory card into the camera. Otherwise, you will format the memory card.
- Formatting is an irreversible action and data cannot be recovered at a later time.
- An SD memory card having any problem cannot be properly formatted.

Using the LCD Monitor

Your camera is equipped with a 1.8" full color LPTS LCD monitor to help you compose images, replay recorded images/video clips or adjust menu settings. The mode icons, text and numbers displayed on the monitor may vary according to the current settings.

1. Rotate the mode dial to **A**, **P**, , , , , or .
2. Press the  button to turn on the power.
3. Compose your scene on the LCD monitor.
4. Press the shutter button.








NOTE

- The LCD monitor darkens in strong sunlight or bright light. This is not a malfunction.
- To prevent your images from being blurred while pressing the shutter button, always hold it carefully. This is especially important when you are shooting under low lighting conditions, which your camera may decelerate the shutter speed to ensure your images are properly exposed.

PHOTOGRAPHY MODE

Shooting Images – The Basics

1. Rotate the mode dial to **A**, **P**, , , , or  and turn your camera on by pressing the  button.
2. Compose the image on the monitor screen so that the main subject is within the focus frame.



3. Press the shutter button down half way to focus the image.
 - When you press the shutter button down half way, the camera's Auto Focus feature automatically focuses the image and exposure.
4. Press the shutter button the rest of the way down to capture the image.



NOTE

- The actual captured image appears to be larger than the one on LCD after the image is captured.
- Pressing the **|O|** button switches the LCD monitor display mode. Each time you press the **|O|** button, the display changes in the following order: Focus Frame On → Indicators Off → Composition Line On → LCD Off.

Setting Image Resolution and Quality


As you get to know the digital camera, you can set the image resolution (number of vertical and horizontal pixels) and image quality (compression ratio) based on the types of images you want to shoot.







These settings affect the number of images that can be stored in memory, or on a memory card.

Higher resolution and higher quality images provide finer detail but cause the images' file size to be larger.

To change image resolution or image quality, perform these steps below:

1. Rotate the mode dial to **A**, **P**, **Portrait**, **Macro**, **Sports**, or **Movie** and turn your camera on by pressing the **Power** button.





2. Press the  button.
 - The [PICTURE] menu is displayed.
3. Use  to select [IMAGE SIZE], then press the  button.
4. Use  or  to select the desired setting, then press the  button to confirm.
5. Follow the step 3 and 4 above to set the [QUALITY].





NOTE

- The possible number of shots and recording time depend on the storage size, resolution and quality settings and the subject of the image to be captured.
- You can resize the images later. (Please refer to section in this manual titled “**Resizing an Image**” for further detail.)

Using the Zoom Function





This camera is equipped with 3x optical zoom. The lens moves during the optical zoom photography, allowing you to capture telephoto and wide-angle shots. By using the optical zoom function; images appear closer by pressing the  button, or smaller away by pressing the  button.

You can further enlarge the subjects with 4x digital zoom by pressing continuously the  button. It is activated after your camera reaches its maximum optical zoom factor (3x). A useful feature as it is, however, the more the image is magnified, the grainer the image may become.



To capture a zoomed image, perform the following steps:

1. Press the  button to turn on the power.

2. Adjust the magnification ratio by using the  /  button.
 - To access the optical zoom function, press the  button as far as it can go. Press it again to activate the digital zoom.
 - To exit the zoom photography, press continuously the  button.
 - The status of digital magnification is displayed on the LCD monitor.
3. Compose your scene and press the shutter button.










NOTE


- The digital magnification ranges from 1.0x to 4.0x.
- As you record video clips, the zoom function cannot be activated.




Using the Flash

The flash is designed to function automatically when lighting conditions warrant the use of flash. You can take an image using a desired flash mode to suit your circumstances.

1. Rotate the mode dial to **A**, **P**, , , , or .
2. Press the  button to turn on the power.
3. Toggle  /  until your desired flash mode appears on the LCD monitor.
4. Compose your scene and press the shutter button.








The camera has four flash modes: Red Eye, No Flash (default), Auto Flash and Forced Flash. The table below will help you to choose the appropriate flash mode:


Flash mode	Description
 AUTO FLASH	The flash fires automatically according to the photographic conditions.

 RED EYE	Use this mode to reduce the red-eye phenomenon when you want to take natural-looking photographs of people and animals in low-light conditions. When taking photographs, the red-eye phenomenon can be reduced by asking the subject (person) to look at the camera or get as close to the camera as possible.
 FORCED FLASH	The flash will always fire regardless of the surrounding brightness. Select this mode for recording images with high contrast (backlighting) and deep shadows.
 NO FLASH	Use this mode in the environment that the flash use is prohibited or under the situation that the distance to the subject is too far away for the flash to have any effect.



Using the Self-Timer

The self-timer can be used in situations such as group shots. When using this option, you should either mount the camera on a tripod (recommended) or rest it on a flat, level surface.

1. Secure the camera to a tripod or place it on a stable surface.
2. Rotate the mode dial to **A**, **P**, , , , or .
3. Press the  button to turn on the power.
4. Toggle  /  until your desired self-timer mode appears on the LCD monitor.



→ **OFF** → **2** → **10** → **10+2**
[NO INDICATION]

5. Compose your scene and press the shutter button.
 - The self-timer function is activated.
 - The photography is then taken after the preset time.
 - To cancel the self-timer at any time, press the shutter or  button, switch the mode dial to another mode or press  to disrupt the sequence.














NOTE

- After one shot is taken, the self-timer mode is turned off.
- If you wish to take another image using the self-timer, repeat these steps.

Adjusting the Exposure (EV Compensation)














You can manually adjust the exposure determined by the digital camera. Use this mode when the proper exposure cannot be obtained, for example, when the contrast (different between light and dark) between the subject and the background is extremely large. The EV compensation value can be set in the range from -2.0EV to $+2.0\text{EV}$.




1. Rotate the mode dial to **P**, , , , or .
2. Press the  button to turn on the power.
3. Press , then use  to select the [AE/AWB] menu.
4. Use  to select [EXPOSURE], then use  or  to set the range of EV compensation value from -2.0EV to $+2.0\text{EV}$.
5. To exit from the menu, press the  button.

Setting White Balance

This feature lets you make adjustments to compensate for different lighting types according to your shooting conditions.

1. Rotate the mode dial to **P**, , , , or .
2. Press the  button to turn on the power.
3. Press , then toggle  to select the [AE/AWB] menu.
4. Use  to select [W. BALANCE], then press the  button.
5. Use  or  to select the desired setting, then press the  button to confirm.
6. To exit from the menu, press the  button.




USING THE MODE DIAL

Auto Mode

A (Auto) mode is the simplest way which allows you to take still pictures without having to set special functions or manual adjustments. The camera sets the optimal focusing and exposure.




1. Rotate the mode dial to **A** mode and turn your camera on by pressing the  button.
2. Compose your subject within the focus frame.
3. Press the shutter button down halfway to focus the image.
 - When you press the shutter button down half way, the camera's Auto Focus feature automatically focuses the image and exposure.
4. Press the shutter button the rest of the way down to capture the image.

Program Mode

In **P** (Program) mode, the camera automatically sets the shutter speed and aperture for taking still images. You can adjust other functions, such as flash mode or continuous shooting mode.





1. Rotate the mode dial to **P** mode and turn your camera on by pressing the  button.
2. Compose your subject within the focus frame.
3. Press the shutter button to capture the image.



Portrait Mode



Select this mode to make people stand out with the background out-of-focus.

1. Rotate the mode dial to  mode and turn your camera on by pressing the  button.
2. Compose your subject within the focus frame.
3. Press the shutter button to capture the image.



Landscape Mode



This mode allows you to take photographs of distant scenery or landscapes.

1. Rotate the mode dial to  mode and turn your camera on by pressing the  button.
2. Compose your subject within the focus frame.
3. Press the shutter button to capture the image.



Sports Mode



This mode allows you to shoot fast moving objects.

1. Rotate the mode dial to  mode and turn your camera on by pressing the  button.
2. Compose your subject within the focus frame.
3. Press the shutter button to capture the image.



Night Mode

This mode allows you to take photographs of people against a dusk or nighttime background.















1. Rotate the mode dial to  mode and turn your camera on by pressing the  button.
2. Compose your subject within the focus frame.
3. Press the shutter button to capture the image.



ADVANCED SHOOTING

Burst

This mode is used for continuous shooting. Pictures are taken continuously while the shutter release button is pressed.

1. Rotate the mode dial to **P**, , , , or  and turn your camera on by pressing the  button.
2. Press , then use  to select the [FUNCTION] menu.
3. Use  to select [CAPTURE MODE], then press the  button.
4. Use  or  to select [BURST], then press the  button.
5. To exit from the menu, press the  button.
 - The  indicator is displayed on the monitor screen.
6. Press the shutter button halfway to lock the focus.
7. Press the shutter button all the way to shoot.
 - Shooting will stop when the shutter button is released.

















NOTE

- In Burst mode, the flash mode will be set to **OFF** automatically.

Auto Exposure Bracketing (AEB)

In this mode, the camera automatically changes the exposure within a set range to take three shots after you press the shutter button once. AEB settings can be combined with exposure compensation settings to extend the adjustment range.

1. Rotate the mode dial to **P**, , , , or  and turn your camera on by pressing the  button.
2. Press , then use  to select the [FUNCTION] menu.
3. Use  to select [CAPTURE MODE], then press the  button.
4. Use  or  to select [AEB], then press the  button.
5. To exit from the menu, press the  button.
 - The  indicator is displayed on the monitor screen.
6. Press the shutter button to shoot.











NOTE









- In AEB mode, the flash mode will be set to **OFF** automatically.


Selecting the Metering Mode

You can select the metering mode that sets which part of the subject to measure to determine the exposure.

1. Rotate the mode dial to **P**, , , , or  and turn your camera on by pressing the  button.
2. Press , then use  to select the [FUNCTION] menu.





3. Use  to select [METERING], then press the  button.
4. Use  or  to select the desired metering mode, then press the  button.
 - [ AVERAGE]: Averages the light metered from the entire frame, but gives greater weight to the subject matter at the center.
 - [ SPOT]: Meters the area within the spot automatic exposure point frame at the center of the LCD monitor.
5. To exit from the menu, press the  button.
6. Compose your subject within the focus frame.
7. Press the shutter button to capture the image.



PLAY MODE - THE BASICS

Viewing Images

You can display the still images you have just captured at a time.

1. Press the  button to turn on the camera.
2. Press the  (Playback) button.
 - The last recorded image appears on the LCD monitor.



3. Use ◀ or ▶ to select the desired images.
- To view the previous image, press the ◀ button.
 - To view the next image, press the ▶ button.








NOTE

- The playback information displayed on the LCD monitor will disappear after seconds of time.
- If there is no image stored in the internal memory or on the memory card. [NO IMAGE] message will appear on the monitor.

Magnifying Images

While reviewing your images, you may enlarge a selected portion of an image. This magnification allows you to view fine details. The zoom factor displayed on the screen shows the current magnification ratio.

1. Press the  (Playback) button.
 - The last recorded image appears on the LCD monitor.
 - To view the previous image, press the ◀ button.
 - To view the next image, press the ▶ button.
2. Adjust the zoom ration by using the Zoom  /  button.
 - To enlarge the selected image, press the  button.
 - To return to the normal image, press the  button.
 - The magnification factor is displayed on the LCD monitor.
3. To view different portion of the images, press the ▲ / ▼ / ◀ / ▶ button to adjust the display area.






NOTE

- The magnification factors range from 1x to 4x (within 7 stages: 1.0x, 1.5x, 2.0x, 2.5x, 3.0x, 3.5x and 4.0x).

Thumbnail Display (Index Playback)

This function allows you to view four or nine thumbnail images on the LCD monitor simultaneously so you may search for a particular image.








1. Press the (Playback) button.
 - The last recorded image appears on the LCD monitor.
2. Press the / button once.
 - Nine thumbnail images are displayed simultaneously.
- For recorded video clips, the video mode icon will be displayed.
3. Use the / / / button to move the cursor to select the image to be displayed at regular size.
4. Press the button to display the selected image on full screen.




Slideshow Display

The slide show function enables you to play your images back automatically in sequential order. This is very useful and entertaining feature for reviewing recorded images and for presentations.

1. Press the (Playback) button.
 - The last recorded image appears on the LCD monitor.

2. Press , then use  to select [SLIDE SHOW] and press the  button.
3. Use  or  to set the playback interval, then press the  button.
 - The slide show starts.
 - The video clips are displayed the first frame image, and not played back.
 - To stop the slide show, press the  button.
















NOTE


- You can adjust the slide show display interval within the range of 3 SEC., 5 SEC., 10 SEC.

Resizing an Image

You can change the image size of a captured image to one of the following sizes: 2560 x 1920 pixel, 2048 x 1536 pixel, 1280 x 960 pixel and 640 x 480 pixel.

1. Press the  (Playback) button.
 - The last recorded image appears on the LCD monitor.
2. In  (Playback) mode, use  or  to select the desired images.
 - To view the previous image, press the  button.
 - To view the next image, press the  button.



- Press  to access in PLAYBACK menu, then use  or  to select [RESIZE] and press the  button.
- Use  or  to select the desired setting, then press the  button to confirm.



MOVIE MODE

Recording Video Clips

This mode allows you to record video clips with sound via the built-in microphone.

- Rotate the mode dial to  mode and turn your camera on by pressing the  button.
- Press the shutter button to start recording.
- To stop recording, press the shutter button again.





NOTE

- The function of optical zoom (3x) can be activated before you start to record video clips.
- Pressing the button switches the LCD monitor display mode. Each time you press the button, the display changes in the following order: Focus Frame On → Indicators Off → Composition Line On → LCD Off.

Playing Back Video Clips

You can play back recorded video clips. A guide to operation appears on the LCD monitor during the video playback.

1. Press the (Playback) button.
2. Use or to go through the images until the video clip you want to play back is displayed.
 - To view the previous image, press the .
 - To view the next image, press the .
3. Press the button to start playing back the video clips.
 - To pause or resume video playback, press the button again.



NOTE


- The playback information displayed on the LCD monitor will disappear after one second.
- The zoom function cannot be activated while playing the video clips back.
- To playback the video clips on the computer, we recommend you to use Windows Media Player 9.0 (WMP 9.0). You can download this WMP version from the website at www.microsoft.com.

PLAY MODE - ADVANCED FUNCTIONS

Playing Back Images/Video Clips on TV

You can also playback your images on a TV screen. Before connecting to any device, make sure to select NTSC/PAL system to match the video output system of the video equipment you are going to connect to the digital still camera, then turn all connected devices off.

1. Connect one end of the A/V cable to the A/V terminal of the digital camera.
2. Connect the other end to the A/V input socket of the TV set.
3. Turn the TV and digital camera on.
4. Playback the images/video clips.



- The method of operation is the same as playing back still images and video clips on the digital camera.



NOTE






- The sound recorded with video clips can only be played back on TV or computers.

Deleting Images/Video Clips

Use this function to delete one or all images/video clips stored in the internal memory or memory card.















Please note that the deleted images or video clips cannot be recovered. Exercise caution before deleting a file.

■ To delete the latest single image/video clip

1. Press the  button to turn on the power.
2. Press . When the delete message appears, use  or  to select [YES], then press the  button to delete the last image or video clip.
 - If you wish to cancel the deletion, select [NO].



■ To delete image/video clip by preference

1. Press the  (Playback) button.
 - The last recorded image appears on the LCD monitor, which can also be deleted directly by pressing .
2. Use  or  to select the image you want to delete.
3. Press , then use  or  to select [DELETE] and press the  button.
4. Use  or  to select [THIS IMAGE] or [ALL IMAGES] by your preference, then press the  button.
5. When the delete message appears, use  or  to select [YES], then press the  button to confirm the deletion.
 - If you wish to cancel the deletion, select [NO].





NOTE

- Protected images cannot be deleted with the delete function.

Protecting Images/Video Clips

Set the data to read-only to prevent images from being erased by mistake.















- Press the (Playback) button.
 - The last recorded image appears on the LCD monitor.
- In (Playback) mode, use or to select the desired images.
 - To view the previous image, press the button.
 - To view the next image, press the button.
- Press , then use to select [PROTECT] and press the button.
- Use or to choose the desired setting, then press the button.
 - [PROTECT ONE]: Protect one image/movie.
 - [PROTECT ALL]: Protect all images/movies (at once).
- Use or to select [LOCK], then press the button to confirm.
 - Press to return to the (Playback) mode.
 - The indicator appears on the selected image.
 - If you wish to cancel the protect function, select [UNLOCK].












Setting the DPOF

DPOF (Digital Print Order Format) allows you to embed printing information on your memory card. By using DPOF, you can select an image to be printed and then specify how many prints or which image you would like. Take your memory card to a DPOF enabled printer that accepts memory cards. The DPOF/card-compatible printer will read the embedded information on the memory card and print your images as specified.


■ To configure print settings for a single image / all images.

Step	Figure	Procedure
1		Press the  (Playback) button, then use  or  to select the desired image you want to mark  . * The playback information displayed on the LCD monitor will disappear after one second.
2		Press the  button. Use  or  to select [DPOF], then press the  button.
3		Use  or  to select by your preference, then press the  button. [ONE IMAGE]: To configure print settings for a single image. [ALL IMAGES]: To configure print settings for all images. [RESET ALL]: Returns all basic settings to the digital camera's default settings.

4	<div></div> <div></div>	<p>Use ▲ or ▼ to select your preference, then press the button.</p> <p>[QUANTITY]: Allows you to select image quantity (0~10). Use ◀ or ▶ to set the image quantity.</p> <p>[DATE]: The date of recording can be printed directly on the images.</p> <p>Press the  button to choose [YES] or [NO] with ◀ or ▶.</p> <p>[RETURN]: To exit the mark function, use ▲ or ▼ to select [RETURN], then press the  button.</p>
5	<div></div> <div></div>	<p>Press  to return to the image playback mode.</p> <p>* The  is marked on the displayed image.</p> <p>To unmark the  mark, go back to step 3 to select [RESET ALL] with ▲ or ▼.</p>










NOTE

- Before you perform the DPOF settings on your camera, always remember to copy your images from the internal memory to an SD memory card first.
- The  print icon will appear on the monitor indicating images selected for printing.
- You cannot print movies.


Connecting to a PictBridge Compliant Printer

Even if you do not have a computer, you can connect the camera directly to a printer that supports PictBridge to perform image selection and printing using the camera monitor screen and controls. DPOF support also lets you specify which images you want to print and how many copies of each should be printed.

Connecting the camera to the printer



1. Rotate the mode dial to  and turn your camera on by pressing the  button.
2. Press  to select the [CUSTOM] menu, then use  to select [USB].
3. Use  or  to select [PRINT], then press the  button.
4. Connect your camera and the printer via the supplied USB cable.

- The screen turns off automatically and the setting screen will appear on the monitor after one second.















Printing images

When the camera is properly connected to a PictBridge compliant printer, the [PRINT





MODE SELECT] screen is displayed on the monitor. Use  or  to select the print mode.



■ In [PRINT] Mode: Lets you print the specified image with PictBridge.

Step	Figure	Procedure
1		Use ▲ or ▼ to select the [PRINT] mode, then press the  button. * The [PRINT PAPER] screen is displayed.
2		Use ▲ or ▼ to access in the selection of paper setting, then press  the button to confirm. [SIZE]: You may select the desired item depending on the type of printer being used. [BORDERLESS]: You may select the desired item depending on the type of printer being used.
3		Use ◀ or ▶ to select the image you want to print, then press ▼ to proceed for more detailed settings. * The [PRINT INFO] screen is displayed.
4		Use ▲ or ▼ to select your preference, then press the  button. [ x]: Specifies the number of prints. You can select the number up to 10. [DATE]: If you select WITH, images are printed with the date.

		<p>[FILE NAME]: If you select WITH, images are printed with the file name.</p> <p>[CANCEL]: To cancel the print settings, use ▲ or ▼ to select [CANCEL].</p>
5		<p>After step 4 is finished, you can still use ▲ or ▼ to change the image by your preference, then press the (OK) button to print.</p>
6		<p>Use ▲ or ▼ to select [PRINT], then press the (OK) button to confirm.</p> <p>* The TRANSFERRING screen is displayed.</p>
7		<p>This starts printing and displays the message "TRANSFERRING" on the monitor screen. The message will disappear after the printing finished.</p>
		<p>* To cancel printing:</p> <p>Pressing the (OK) button during print data transfer displays the screen for selecting whether to [CONTINUE] or [CANCEL] printing.</p>

- **In [PRINT ORDER] Mode:** This function only lets you print the specified image based on the previous

Step	Figure	Procedure
1	 The screen displays 'PRINT MODE SELECT' at the top. Below it are two options: 'PRINT' and 'PRINT ORDER'. 'PRINT ORDER' is highlighted. At the bottom, there is a 'SELECT:' label with up/down arrows and a 'SET: (OK)' button.	Use ▲ or ▼ to select the [PRINT ORDER] mode, then press the (OK) button. * The [PRINT PAPER] screen is displayed.
2	 The screen displays 'PRINT PAPER' at the top. Below it is the 'SIZE' section with '<STANDARD>' selected. Below that are 'BORDERLESS' and 'STANDARD' options. At the bottom, there is a 'SELECT:' label with up/down arrows and a 'SET: (OK)' button.	Use ▲ or ▼ to access in the selection of paper setting, then press the (OK) button to print. [SIZE]: You may select the desired item depending on the type of printer being used. [BORDERLESS]: You may select the desired item depending on the type of printer being used.
3	 The screen displays 'PRINT' at the top. Below it are two options: 'PRINT' and 'CANCEL'. 'PRINT' is highlighted. At the bottom, there is a 'SELECT:' label with up/down arrows and a 'SET: (OK)' button.	Use ▲ or ▼ to select [PRINT], then press the (OK) button to confirm. * The TRANSFERRING screen is displayed.
4	 The screen displays a camera icon, a large 'Z' icon, and a printer icon. Below them is the word 'TRANSFERRING'. At the bottom, there is a 'CANCEL: (OK)' button.	This starts printing and displays the message "TRANSFERRING" on the monitor screen. The message will disappear after the printing finished.

		<p>* To cancel printing:</p> <p>Pressing the  button during print data transfer displays the screen for selecting whether to [CONTINUE] or [CANCEL] printing.</p>
--	---	--

TRANSFERRING RECORDED IMAGES TO YOUR COMPUTER

After using USB cable to establish a USB connection between the camera and your computer, you can use your computer to share recorded images/video clips/voice-recording files with your family or friends via a e-mail or post them on the Web. In order to do this, you must install the USB driver onto your computer first. Note that before you begin to install the software, you need to check your system according to the table as shown below.

	System requirements (Windows)	System requirements (Macintosh)
CPU	Pentium III 600 MHz processor or higher	PowerPC G3/G4
OS	Windows 98/98SE/Me/2000/XP	OS 9.0 or later
Memory	64MB RAM	64MB RAM
Free Space on Hard Disk	128MB hard disk space	128MB hard disk space
Required Devices	A CD-ROM drive, An available USB port	A CD-ROM drive, An available USB port
Display	Color monitor (800x600, 24-bit or higher recommended)	Color monitor (800x600, 24-bit or higher recommended)

Step 1: Installing the USB driver on Windows computers

■ Installation on Windows 98 & 98SE







The USB driver on the supplied CD-ROM is exclusively for Windows 98 and 98SE. Windows 2000/ME/XP users need not install the USB driver.


1. Insert the enclosed CD-ROM into your CD-ROM drive.
2. When the welcome screen appears, click **"INSTALL USB DRIVER"**.
 - Follow the on-screen instructions to complete the installation.
3. After the USB driver has been installed, restart your computer.

■ Installing the USB driver on Macintosh computers

For Mac OS 9.0 or higher, the computer will automatically recognize the camera and load its own USB drivers.

Step 2: Connecting the digital still camera to your computer

1. Rotate the mode dial to  and turn your camera on by pressing the  button.
2. Press  to select the [CUSTOM] menu, then use  to select [USB].
3. Use  to select [PC], then press the  button.
4. Connect one end of the USB cable to an available USB port on your computer.
5. There will be a new "Removable Disk" icon detected in "My Computer", in which contains your recorded images or video clips.



Mac users: Double-click the "untitled" or "unlabeled" disk drive icon on our desktop. iPhoto may automatically launch.

Step 3: Downloading images/video clips

When the camera is turned on and connected to your computer, it is considered as a disk drive, just like a floppy disk or CD.

You can download (transfer) images/video clips by copying them from the "removable disk" ("untitled" disk on a Macintosh) to your computer hard drive or to another kind of disk.

For computers running Windows

Open the "removable disk" by double-clicking on it. Double-click on the folder that contains your recorded images/video clips. Select the images/video clips that you prefer and choose "Copy" from the "Edit" menu. After that, open the destination location and choose "Paste" from the "Edit" menu.

For computers running Mac OS

Open the "untitled" disk window and the hard disk or the destination location. Drag and drop from the camera disk to the desired destination.



NOTE

- Memory card users may prefer to use a memory card reader (highly recommended).
- Video playback application is not included with the package. Make sure that video playback application has been installed in your computer.

EDITING SOFTWARE INSTALLATION

Installing Photo Explorer

Ulead® Photo Explorer provides a simple and efficient way to transfer, browse, modify and distribute digital media. Acquire photos, video or sound clips from various digital device types and easily browse or add personal descriptions; make timely modifications; or distribute the media through the medium of your choice: E-mail, Print, Slideshow Presentations. It is an indispensable all-in-one tool for owners of digital cameras, WebCams, DV camcorders, scanners, or anyone who strives to effectively organize a large collection of digital media.

1. Insert the enclosed CD-ROM into your CD-ROM drive.

2. When the welcome screen appears, click **"Install Ulead® Photo Explorer"**. Follow the on-screen instructions to complete the installation.

**NOTE**

- For more information about the operation of Photo Explorer application software, refer to its respective help documentation.
- For Windows 2000/XP users, please make sure to install and use the Photo Explorer in "Administrator" mode.
- Photo Explorer is not supported on the Mac. iPhoto or iPhoto2is recommended.

Installing Photo Express

Ulead® Photo Express is complete photo project software for digital images. The step-by-step workflow, visual program interface, and in-program help assist users in creating exciting photo projects. Acquire digital photos effortlessly from digital cameras or scanners. Organize them conveniently with the Visual Browse mode. Use hundreds of ready-to-use templates such as albums, cards, posters, slideshows, and more. Edit and enhance images with photo editing tools, photographic filters, and special effects. Embellish projects by adding creative design elements such as frames, callouts, and stamp objects.

Share results with family and friends via e-mail and multiple print options.

1. Insert the enclosed CD-ROM into your CD-ROM drive.
2. When the welcome screen appears, click **"Install Ulead® Photo Express"**. Follow the on-screen instructions to complete the installation.

**NOTE**

- For information on how to use Photo Express to edit and retouch your recorded images, please refer to its online help.
- For Windows 2000/XP users, make sure to install and use the Photo Express while logged in as a user with an Administrator account.
- Photo Express is not supported on the Mac.

USING THE DIGITAL STILL CAMERA AS A PC CAMERA

Your digital still camera can act as a PC camera, which allows you to videoconference with business associates, or have a real-time conversation with friends or family. To use the digital still camera for videoconferencing, your computer system must include the items as below:

- Microphone
- Sound card
- Speakers or headphones
- Network or Internet connection



NOTE








- Video conferencing (or video editing) software is not included with the digital still camera.
- This mode is not supported for Mac.


Step 1: Install the PC camera driver (same as USB driver)

The PC-camera driver included in the CD-ROM is exclusively for Windows. The PC camera function is not supported for Mac platforms.

1. Insert the enclosed CD-ROM into your CD-ROM drive.
2. When the welcome screen appears, click “ **DRIVER For PC CAM** ”.
Follow the on-screen instructions to complete the installation.
3. After the driver installation is completed, restart your computer.

Step 2: Connect the digital still camera to your computer

1. Rotate the mode dial to  and turn your camera on by pressing the  button.
2. Press  to select the [CUSTOM] menu,
then use  to select [USB].
3. Use  or  to select [PC CAM.], then
press the  button.
4. Connect one end of the USB cable to an
available USB port on your computer.
5. Position the digital camera steadily on top of your computer monitor or use a tripod.



NOTE

- When using this digital still camera as a PC camera, it is necessary to install the battery into the digital still camera.

Step 3: Run your application software (i.e. Windows NetMeeting)

To use Windows NetMeeting for videoconferencing:

1. Go to **Start** → **Programs** → **Accessories** → **Communications** → **NetMeeting** to launch the NetMeeting program.
2. Click the **Start Video** button to view live video.
3. Click the **Place Call** button.
4. Type the e-mail address or the network address of the computer that you are calling.
5. Click **Call**. The person that you are calling must also have Windows NetMeeting running and be willing accept your call to start the videoconference.




NOTE

- The video resolution for videoconferencing applications is generally 320 x 240.
- For more information about the operation of videoconference application software, refer to its respective help documentation.

MENU OPTIONS










Camera Menu

This menu is for the basic settings to be used when capturing still images.



























1. Rotate the mode dial to **A**, **P**, , , or and turn your camera on.
2. Press , then use or to select the [PICTURE] / [FUNCTION] / [AE/AWB] menu.
 - In **A** (Auto) Mode, press to access in menu directly.
3. Press or to select the desired setting, then press the button.
4. To exit from the menu, press the button.


■ In **A** (Auto) Mode

Item	Description
IMAGE SIZE 	Sets the size of the image that will be captured. 5M 2560 x 1920 3M 2048 x 1536 1.2M 1280 x 960 0.3M 640 x 480
QUALITY 	Sets the quality (compression rate) at which the image is captured. [★★] FINE [★★★] NORMAL [★] ECONOMY
FOCUS 	You can take images with the distance to the subject set by auto focus, macro or infinity. * AUTO *  MACRO *  INFINITY
CAPTURE MODE 	Sets the recording method at the time of taking pictures. *  SINGLE *  BURST *  AEB

■ In P, , ,  or  Mode


Item	Description
IMAGE SIZE 	Refer to "Camera Menu - In A (Auto) Mode" in LIST OF MENU OPTIONS.
QUALITY 	Refer to "Camera Menu - In A (Auto) Mode" in LIST OF MENU OPTIONS.
SHARPNESS 	Sets the level of image sharpness. *  LOW *  MEDIUM *  HIGH
COLOR 	Sets the color of the image that will be captured. *  FULL COLOR *  BLACK & WHITE *  SEPIA
SATURATION 	To capture an image, your camera offers you three different degrees of color to match with your preference. Your images will demonstrate different impression by selecting different degrees of color. This is called "Saturation". *  LOW *  MEDIUM *  HIGH





Item	Description
FOCUS 	Refer to "Camera Menu - In A (Auto) Mode" in LIST OF MENU OPTIONS.
CAPTURE MODE 	Refer to "Camera Menu - In A (Auto) Mode" in LIST OF MENU OPTIONS.
METERING 	Refer to section in this manual titled "Selecting the Metering Mode" for further details.
EXPOSURE 	<p>Sets to obtain the correct exposure when the subject is much brighter or darker than the background.</p> <p>The EV compensation value can be set in the range from -2.0EV to +2.0EV.</p>
W. BALANCE 	<p>Sets the white balance photographing under a variety of lighting conditions and permits photographs to be taken that approach the conditions that are seen by the human eye.</p> <ul style="list-style-type: none"> * AUTO *  DAYLIGHT *  CLOUDY *  SUNSET *  TUNGSTEN *  FLUORESCENT






Item	Description
ISO 	Sets the sensitivity for taking pictures. When the sensitivity is raised (and the ISO figure is increased), photography will become possible even in dark locations, but the more pixilated (grainer) the image will appear. *AUTO / 50 / 100 / 200

Video Menu


This menu is for the basic settings to be used when recording video clips.










1. Rotate the mode dial to  mode and turn your camera on.
2. Press , then use  to select the [COLOR].
3. To exit from the playback menu, press the  button.



Item	Description
COLOR 	REFER TO "Camera Menu-In In P ,  ,  ,  or  Mode" of MENU OPTIONS.













Play Menu

In the  (Playback) menu, set which settings are to be used for playback.




1. Press  the (Playback) button.
 - The last recorded image appears on the LCD monitor.
2. Press , then use  or  to select the desired setting and press the  button.
3. To exit from the playback menu, press the  button.







Item	Description
DELETE 	Delete one or all images you captured. * Refer to section in this manual titled “Deleting Images/Video Clips” for further details.
SLIDE SHOW 	You can play back recorded images in order with a selected interval time. This function is useful for checking your images or for presentations, etc. Refer to section in this manual titled “Slideshow Display” for further details. * 3 SEC. / 5 SEC. / 10 SEC.

Item	Description
PROTECT 	Set the data to read-only to prevent images from being erased by mistake. Refer to section in this manual titled "Protecting images/Video clips" for further details. * Refer to section in this manual titled is "Protecting Images/Video Clips" for further details.
QUALITY CHANGE 	Change to set the desired quality (compression rate) at which the image is captured.  FINE  NORMAL  ECONOMY
RESIZE 	Changes the size of a recorded image.  2560 x 1920  2048 x 1536  1280 x 960  640 x 480
DPOF 	Allows you to select the desired pictures to be printed and set the number of prints and date displayed in DPOF format. You can print images easily just by inserting the memory card to a DPOF-compatible printer or a print shop. Refer to section in this manual titled "Setting the DPOF" for further details.
COPY TO CARD 	Allows you to copy your files from the digital camera's internal memory to a memory card. Of course, you can only do this if you have a memory card installed and some files in internal memory. * YES / NO



Setup Menu







This feature allows you to set up the default settings by preference for using your camera.








1. Rotate the mode dial to  (Setup) mode and turn your camera on.
2. Press  or  to select the [BASIC] / [CUSTOM] menu.
3. Use  or  to select the desired option item, then press the  button.
4. To exit from the setup menu, rotate the mode dial to other desired mode again.

■ BASIC Settings


Item	Description
BEEPER 	This sets whether or not to mute the startup sound and the camera sound each time you press the camera button. * LOUDER / SOFT / OFF
POWER OFF 	If no operation is performed for a specific period of time, the power to the camera is automatically turned off. This feature is useful to reduce battery wear. * 2 MIN. / 3 MIN. / 5 MIN. / OFF

Item	Description
DIGITAL ZOOM 	<p>This sets whether or not to use digital zoom at the time of photography.</p> <p>* ON / OFF</p>
SET TO DEFAULT 	<p>Returns all basic settings to the digital camera's default settings. The time setting will not be reset.</p> <p>* YES / NO</p>
RESET NUMBER 	<p>Set whether or not to reset the file number when you take photographs. This creates a new folder. The captured images are recorded to the newly created folder from number 0001. If you want to reset the file number, be sure that no images are recorded in the internal memory or the SD memory card.</p> <p>* YES / NO</p>
DATE IMPRINT 	<p>The date of recording can be printed directly on the still images. This function must be activated before the image is captured.</p> <p>* ON / OFF</p>
FORMAT 	<p>Erases all images and reformats the SD card loaded in your camera. Protected images are also erased. SD card cannot be formatted if it is write-protected.</p> <p>Refer to section in this manual titled "Formatting an SD Memory Card or Internal Memory" for further details.</p> <p>* YES / NO</p>
QUICK VIEW 	<p>Set to display a photographed image on LCD monitor immediately after you have taken the shot.</p> <p>* ON / OFF</p>

■ CUSTOM Settings

Item	Description
DATE & TIME  Y/M/D	This sets the date and the time. Refer to section in this manual titled "Setting the Date and Time" for further details. * Y/M/D * D/M/Y * M/D/Y
TV  NTSC PAL	Sets video output system of the video equipment that you are going to connect to the camera. * PAL / NTSC
LANGUAGE 	Sets the language that is displayed on the LCD monitor. Refer to section in this manual titled "Choosing the Screen Language" for further details.
LCD BRIGHTNESS 	This sets the brightness of the LCD monitor. The adjustment range is from -5 to +5.
USB  USB	Select to choose one of the following modes for further settings. * PC / PRINT / PC CAM.

CONNECTING THE CAMERA TO OTHER DEVICES



CAMERA SPECIFICATIONS







Item	Description
Image Sensor	CCD
Effective pixels	5.0 Mega pixels
Image size	Still image: 2560 x 1920, 2048 x 1536, 1280 x 960, 640 x 480 Video clip: 320 x 240
Image quality	Still image: Fine, Normal, Economy Movie image: Economy
Recording media	12MB internal memory SD memory card (Optional, up to 512 MB)
File format	Motion JPEG (AVI); Picture Bridge support; PC-CAM support (QVGA around 20 f/s)
Lens	F-no.: Wide: 2.8 / Tele: 4.8 Focal length: 5.4mm-16.2mm (Equivalent to 35mm Camera: 32~96 mm)
Focus range	Normal: 50 cm-infinity Wide: 6 cm-infinity Tele: 35 cm-infinity
LCD monitor	1.8" LTPS color LCD High-resolution 130K pixels display
Self-timer	10 sec delay, 2 sec delay, 10+2 sec delay
Exposure compensation	-2.0EV~ +2.0EV (in 0.3EV increments)
White balance	Auto, Daylight, Cloudy, Sunset, Tungsten, Fluorescent
ISO	Auto, 50, 100, 200


Interface	DC-IN jack, USB connector, A/V terminal
Power	2 x AA Alkaline batteries (Optional) AC-DC Adapter (3V/2.5A) (Optional)
Dimension	Approx. 91 x 61 x 27 mm
Weight	Approx. 130g (without batteries and the SD memory card)

* Design and specifications are subject to change without notice.

APPENDIX

■ Troubleshooting Guide

Symptom	Possible causes	Solutions / Corrective Actions
Power does not turn on.	<ul style="list-style-type: none"> ■ The battery has run out. ■ The battery is not oriented correctly. ■ The battery cover is not closed properly. ■ The AC power adapter (optional) is disconnected. 	<ul style="list-style-type: none"> ■ Load new or fully charged battery. ■ Load the battery in the correct direction. ■ Close the battery cover correctly. ■ Properly connect the AC power adapter.
Camera suddenly powers down.	<ul style="list-style-type: none"> ■ The function of POWER OFF in  (Setup) mode has been activated. ■ The battery has run out. 	<ul style="list-style-type: none"> ■ Set the option of POWER OFF to OFF. ■ Turn the power back on or charge the battery.
Image is not captured when the shutter button is pressed.	<ul style="list-style-type: none"> ■ The camera is in  PLAY mode. ■ Memory is full. 	<ul style="list-style-type: none"> ■ Rotate the mode dial to A, P, , , , or . ■ Transfer the desired files to your computer and then delete unnecessary files, or use a different memory card.

Flash does not fire.	<ul style="list-style-type: none"> ■ NO FLASH is selected in flash mode. ■ The camera is in BURST/AEB/  (Video) mode. 	<ul style="list-style-type: none"> ■ Select a different flash mode. ■ Select [SINGLE] in the capture mode.
Continuous shooting is not possible.	<ul style="list-style-type: none"> ■ The capacity of the built-in memory or SD memory card is full. 	<ul style="list-style-type: none"> ■ Insert a new SD memory card.
Cannot transfer files over a USB connection.	<ul style="list-style-type: none"> ■ USB cable is not connected securely. ■ USB driver is not installed. ■ Camera is turned off. 	<ul style="list-style-type: none"> ■ Check all connections. ■ Install the USB driver on your computer. ■ Turn on the camera.

Possible Number of Recordable Images

The frame counter indicates the approximate number of images that can be stored on the SD memory card. The number of recordable images may vary depending on the recorded subject, the capacity of the memory card, there are files other than images or when the recording is made while switching the picture quality or resolution.

Resolution	Quality (Compression Ratio)	SD Memory Card					
		12MB Internal Memory	32MB	64MB	128MB	256MB	512MB
5M 2560 x 1920	★★ FINE (1/4)	4	12	24	48	96	192
	★ NORMAL (1/8)	8	24	48	96	192	384
	★ ECONOMY (1/16)	17	40	80	160	320	640
3M	★★ FINE (1/4)	6	20	40	80	160	320

2048 x 1536	★NORMAL (1/8)	13	40	80	160	320	640
	★ECONOMY (1/16)	27	64	128	256	512	1024
1.2 M 1280 x 960	★★ FINE (1/4)	17	52	104	208	416	832
	★NORMAL (1/8)	33	108	216	432	864	1728
	★ECONOMY (1/16)	64	164	328	656	1312	2624
0.3 M 640 x 480	★★ FINE (1/4)	64	220	440	880	1760	3520
	★NORMAL (1/8)	128	440	880	1760	3520	7040
	★ECONOMY (1/16)	257	660	1320	2640	5280	10560

* The data shows the standard testing results. The actual capacity varies according to the shooting conditions and settings.

Approximate Duration of Recording Time

The table below indicates the approximate duration of recording time depending on the capacity of the SD memory card.

Image size	SD memory card					
	12MB Internal Memory	32MB	64MB	128MB	256MB	512MB
320 x 240	39	2:21	4:54	9:43	20:22	38:06

* The data shows the standard testing results. The actual capacity varies according to the shooting conditions and settings.